



### LS-100 Fractional Pricing Support

1. Make sure that the scale is plugged into a proper outlet and that the *Power Switch* is **OFF**.
2. Locate the *CAL Switch* which is under the platter on the front left side of the scale.  
**You may need to remove the *CAL Plate* to expose the *CAL Switch*.**
3. Press and hold down the *CAL Switch* as you place the *Power Switch* in the **ON** position.
4. Once the displays read , release the *CAL Switch*.
5. Make sure that there is nothing on the platter. Press , .
6. Now press      and then press .
7. Press  & then press the  key until the displays read: 
8. You can press the  or  key to turn the Fractional Pricing feature ON or OFF.
9. Press  and then , , , , and then .
10. You are done.

If further problems persist, please contact the Atron Systems Service Department at 973-227-8882.