


Programming for Units for PX-Series Scales

1. Turn the scale ON and once the display shows the ROM version number, press the  key.





*Note: The version number may vary.

2. The display will then show:




3. Press , , , , and then .

4. The display should look like this:


 and then 


5. Press the  key repeatedly until the display reads F11:




6. Now press the  key and the display will look like this:


 then  then 




7. You can use the  key to enable or disable the Pounds unit of measure.


8. Now press the  key and the display will look like this:


 then  then 




9. You can use the  key to enable or disable the Ounces unit of measure.


10. Now press the  key and the display will look like this:


 then  then 


11. You can use the  key to enable or disable the Kilograms unit of measure.


12. Now press the  key and the display will look like this:

 then  then 

13. You can use the  key to enable or disable the Grams unit of measure.

14. Now press the  key and the display will look like this:

 then  then 

15. You can use the  key to enable or disable the Pieces unit of measure.

16. Now press the **TARE** key and the display will look like this:



17. You can use the **UNIT** key to enable or disable the Percent unit of measure.

18. Now press the **TARE** key and the display will look like this:



19. You can use the **UNIT** key to enable or disable the Pound-Ounce unit of measure.

20. Now press the **TARE** key and the display will look like this:



21. Press **ZERO** the key and the scale will do the Display Self-Test and then go to zero.

If any problems persist, please contact the Atron Systems Service Department at 973-227-8882.